
Quick Installation Guidance Model:LFP 2400/2500/5000







02 Wall Mounting







Drill holes of M8 in the wall at least 50 mm depth according to the positioning cardboard
















07 Battery Address DIP Switch Setting





For Parallel connection, SW2 DIP 8 select 'OFF' For Series connection, SW2 DIP 8 select 'ON '




Series Connection 1 Battery The series of the series of

























Series Connection 5 Batteries Master Slave 1 Slave 2 Slave 3 Slave 4





Series Connection 6 Batteries Master Slave 1 Slave 2 Slave 3 Slave 4 Slave 5

Parallel Connection 6 Batteries Master Slave 1 Slave 2 Slave 3 Slave 4 Slave 5



Series Connection 7 Batteries Master Slave 1 Slave 2 Slave 3 Slave 4 Slave 5 Slave 6

7 Batteries Master Slave 1 Slave 2 Slave 3 Slave 4 Slave 5 Slave 6

Parallel Connection



